

7.2 Components diagram




Fig. 14 Components Diagram

7.3 Parts list

Item	Description	Reference
1	Screw	8 716 461 314
2	Heating body	8 705 406 235 0
3	Hydrogenerator	8 707 406 069 0
4	Wire form spring	8 701 201 020 0
5	O-ring	8 700 205 023 0
6	Wire form spring	8 704 705 030 0
7	Cold water pipe	8 700 705 947 0
8	O-ring (10x)	8 700 205 133 0
9	Wire form spring	8 704 705 025 0
10	Temperature limit	8 707 206 017 0
11	Hot water pipe	8 716 416 714
12	Burner	8 708 120 298 0 (NG)
12	Burner	8 708 120 296 0 (LP)
13	Washer 1"	8 710 103 060 0
14	Throttle disc (7,0)	8 700 100 174 0 (LP)
15	Pilot burner (41.2)	8 708 105 491 0 (LP)
15	Pilot burner (41.1)	8 718 105 051 0 (NG)
16	Flame sensor	8 708 107 007 0
17	Pilot injector (13)	8 708 200 069 0 (NG)
17	Pilot injector (74)	8 708 200 312 0 (LP)
18	Pilot gas pipe	8 700 707 370 0
19	Washer	8 700 103 173 0
20	Gas valve	8 707 021 109 0 (NG)
20	Gas valve	8 707 021 108 0 (LP)
21	Diaphragm switch	8 708 504 021 0 (NG)
21	Diaphragm switch	8 708 504 049 0 (LP)
22	Pilot valve	8 708 501 249 0
23	Servovalve	8 708 501 250 0
24	Gas regulator	8 716 487 043 (LP)
24	Gas regulator	8 716 487 044 (NG)
25	Water valve	8 707 002 708 0
26	Water valve cover	8 705 500 101 0
27	Sleeve	8 700 306 114 0
28	Diaphragm (C)	8 700 503 053 0
29	Wire form spring	8 704 705 024 0
30	Inlet water filter	8 700 507 001 0
31	Selector Screw	8 708 500 289 0
32	Volumetric water governor	8 705 705 027 0
33	Venturi (23s)	8 708 205 279 0
34	Switch	8 707 200 014 0
35	Set of cables	8 704 404 050 0
36	Ignition unit	8 707 207 078 0
37	Connecting cable	8 704 401 222 0
38	Piezo electrode	8 708 107 006 0
39	Anti frost device	8 716 459 336
40	Thermostat	8 716 459 273
41	Cold water pipe	8 716 416 715
42	Screw	8 703 401 051 0

Table 5